

INSTALLATION OVERVIEW

201-EBT-20B-WB



This installation overview is not a substitute for reading the product manuals

WHAT'S INCLUDED



1 x 201-217-30 - Gauge and mounting bracket



2 x 218-SK - Weld strain sensor installation kit



Scan here to see additional resources on our website including full installation manuals, quick set up guides, and video tutorials!

SENSOR CONFIGURATION



The gauge should be set to detect 2 Spring Sensors. See *Spring Suspension Gauge* manual for more information on how to set the sensor configuration.

APPLICATIONS


Straight Truck: Walking Beam Spring Suspension (DRIVE AXLE GROUP ONLY)

Sensor Location:

The strain sensors should be mounted on the back left and the front right of the walking beam drive axle group. Make sure they are installed on the top of the beams. See the 218-SK manual for more information on how to install the strain sensors.

Mode:

Set the gauge to Average (AVG) mode to see a single weight for the drive axle group. See *Spring Suspension Gauge* manual for information on how to set the mode.



CONTACT US!

Right Weigh, Inc.
(888) 818-2058
www.rwls.com
support@rwls.com

Follow Us!

